



Item	Part No.	Description
1	CHARGE115.01	TOP COVER (FOR CHARGE115)
2	CHARGE124.02	HANDLE
3	CHARGE115.03A	LOWER PANEL (FOR CHARGE115)
4	CHARGE124.04	AMMETER
5	CHARGE124.05	CABLE BUSHING
6	CHARGE124.06	POSITIVE CLAMP
6A	CHARGE124.06A	NEGATIVE CLAMP
7	CHARGE115.07	FUSE 30Amp
8	CHARGE124.08	SWITCH 12/24V (6PINS)

Item	Part No.	Description
9	CHARGE124.09	WHITE ROCKER SWITCH
10	CHARGE124.10	ON/OFF SWITCH (4 PINS&MARKED I/O)
11	CHARGE124.11	POWER CABLE WITH PLUG
12	CHARGE124.12	RECTIFIER
13	CHARGE115.13	MAIN TRANSFORMER
14	CHARGE124.14	RUBBER FOOT
--	CHARGE115.FS	FUSE SET (NOT SHOWN)
--	CHARGE115.PP	PANEL PARTS (NOT SHOWN)
--	CHARGE124.07A	FUSE HOLDER (NOT SHOWN)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.