

Product Data Sheet

Product Name: Safety Source DRP2V
Our Reference: DRP2V
Quantity Per Box: 10 masks
Quantity Per Case: 120 masks (12 x 10)

Characteristics:

- ***Moulded design** helps retain shape & prevents collapse onto the face
- *High efficiency design
- *4-point elasticated adjustable headband
- *Full inner facial foam seal
- *Adjustable nose clip
- *Exhalation valve for easier exhalation
- *Embossed fully sealed edge, prevents fibre release
- *Contour design
- *Approved to EN149:2001 +A1:2009 (NR)

Applications:

FFP2: protection against non-toxic and low-to-average toxicity solid and liquid aerosols (e.g. oil-mists) in concentrations up to 12 x MAC/OEL/TLV or 10 x APF.

MAC = Maximum admissible concentration

OEL = Occupational exposure limit

TLV = Threshold limit value

APF = Assigned protection factor

Warning Information:

1. Failure to follow all instructions and limitations on the use of this product could reduce the effectiveness of the respirator and result in sickness or ill health.
- 2 A properly selected respirator is essential to protect your health. Before using this respirator, consult your health and safety manager or supplier to determine the suitability for your intended use.
3. This product does not supply oxygen. Use only in adequately ventilated areas containing sufficient oxygen to support life. Do not use this respirator when oxygen concentration is less than 19%.
4. Do not use when concentrations of contaminants are immediately dangerous to health or life.
5. Do not use in explosive atmospheres.
6. Leave work area immediately and return to fresh air if (a) breathing becomes difficult, or (b) dizziness or other distress occurs.
7. Facial hairs or beards and certain facial characteristics may reduce the effectiveness of this respirator.
8. Never alter or modify this respirator in any way.
9. Only for single use. No maintenance necessary. Discard the used respirator after single use in an environmentally friendly way.
10. Keep respirators in the display box away from direct sunlight or contaminants until use.
11. The length of time this respirator can be used depends on the contaminants present but should not exceed one shift. The respirator should be replaced sooner if breathing becomes difficult or if the user notes any irritation, taste or smell.



Certification:

The Safety Source DRP2V respirators meet the requirements of EN149:2001+A1:2009 and are CE marked in accordance with the requirements of European Directive 89/686/EEC and subsequent amendments.

Certified by: British Standards Institution (BSI), Maylands Ave, Hemel Hempstead, Herts, HP2 4SQ, United Kingdom [Notified body No 0086]

Fitting Instructions:



Hold the respirator in one hand with the nose bridge up. Allow strap to hang freely and gently open the respirator.



Position the respirator under the chin covering mouth and nose.



Pull the headband over the head and position behind the head.